

How to order a spare part?

Take the appropriate spare part list from you manual and inform us the following specifications: **Drawing number, position and part number.**

Pos. 6 + 9 + 12

Bauteile mit UHU Plus Endfest 300 einkleben.
(Klebeanweisung beachten, Klebestellen entfetten)

Glue in parts with UHU Plus Endfest 300.
Follow glue instructions. Do degrease the sticker marks.

Coller les pieces avec UHU Plus Endfest 300.
Respecter instructions de coller, degraisser les endroits de collage.

Kopfstück fest anziehen 10 Nm
Apretar fuertemente el tapon de plastico 10 Nm
serrez lete fermement 10 Nm
screw the top piece down tightly 10 Nm

Achtung: Linksgewinde!
Attention: Filet a gauchel!
Atencion: i Filete a la izquierdal!
Attention: left-hand thread!

position

Pos.	Teile Nr. / part no.	QTY	Benennung	Detail	Title
3	31904107 200	1	Klöppelsockel	IFDA-2Z-100, Kunstst. kompl.	carrier socket
4	833001262	2	Bundbuchse	05-06-08-WFM	bushing
5	42000808	1	Spulenadapter	f. Klöppel IFDA-100	
6	51903304	1	Hülse		sleeve
7	51900225 200	1	Druckbutzen	IFDA-80-100	pressure bolt
8	51900232	1	Druckfeder	zum Druckbutzen	
9	41901338 A	1	Drahtzug-Führung	z. Klöppel JFD 100	
10	31903779	1	Schwinghebel	IFDA-Z-100 N	
11	51903594	1	Bolzen	zum Schwinghebel	bolt
12	51902655 101	2	Stahl-Bundöse		
13	51901399 900	1	Drahtzug	JFD 100 - Stahlauge-verchromt	
15	51900224	1	Druckbolzen	IFD-80	
16	01901235	1	Kopfstück	IFDA-100, kurz, f.Papphülse	
25	830405908	2	Spannstift	ISO_8752_-_2.5_x_30_-A	spring pin

Allgemeintoleranzen R_z25 R_z10 R_z4
DIN 2768-mK
Werkstückkanten müssen gratfrei sein!

Maßstab : 1:2.5

ca. Gewicht :

Werkstoff : _____ Nr.

Modell-Nr. : _____ EDV-Nr.

Benennung

Klöppeloberteil

Rot, IFDA-2-100, f. Papphülse

NAME _____

DATUM _____

ÄMT.Nr. _____

NAME **J.Meyer**

DATUM **19.06.2008**

ÄMT.Nr. _____

Ansicht aktualisiert

part description

carrier upper part

HERZOG®

Urheberrecht geschützt gemäß DIN 34

Datum	Name
Bearb. 07.07.2004	Kappen
Gepr.	
Freig. 19.06.2008	J.Meyer

Zeichnung Nr. **01901447 300**

part No.

Blatt 1

v. 1 Bl.

Ers. f.

Ers. d.

or please give us the following information:


- **machine-type**
- **machine-number**
- **drawing-number**
- **part number**

For example:

You require a carrier base

- **machine-type:** SE 1/24-120
- **machine-number:** 103950
- **drawing-number:** 20803406 400
- **part number:** I - 2

Where can I find machine-type and machine-number?



The machine-number is also stamped into the upper plate of the machine.

